Cleaning Ultrasonic Cleaner

Clean Water Tank

1 Turn off and unplug ultrasonic cleaner.



2 Make sure ultrasonic cleaner is at room temperature.

CTQ **3** Use container to remove water from tank. Discard water in appropriate waste container.



4 Use lint free wipe to dry control panel and area around ultrasonic cleaner.

5 Clean water tank with lint free wipes moistened with IPA 70%. Allow to dry.

CTQ **6** Document completion on *Deionized Water Change Form.*



 ©2008 Explainers | The Bishop Company

EXPLAINIT®
Integrated Instruction
www.explainers.com